






NARVIK B-1

A  2pcs	B  3pcs	C  1pc
D  2pcs	E  1pc	F  4pcs
G  8pcs	H  6. 3x40 12pcs	I  M6x45 4pcs
J  M6x30 8pcs	K  M6x27 8pcs	L  M6 12pcs
M  M4x14 2pcs	N  M4 2pcs	O  1pc P  1pc



1

Ax2
Ex1
Dx2
Gx8

2

Cx1
Jx4

3

Jx4

4

Bx3
Hx12

5

Lx4
Ix4

6

Fx4
Mx2
Nx2

7

Kx4
Lx4

8

Kx4
Lx4

9